



PIATTO PIANO 26 cm.
DINNER PLATE 26 cm.
H 3 cm.
CODE 01001#001
PCS 06 | BOX 01



PIATTO PIANO 23,5 cm.
DINNER PLATE 23,5 cm.
H 3 cm.
CODE 01002#001
PCS 12 | BOX 01



PIATTO FONDO 23,5 cm.
SOUP PLATE 23,5 cm.
H 4,4 cm.
CODE 01003#001
PCS 12 | BOX 01



PIATTO FRUTTA 20 cm.
DESSERT PLATE 20 cm.
H 2,9 cm.
CODE 01004#001
PCS 12 | BOX 01



PIATTO PANE 17 cm.
BREAD PLATE 17 cm.
H 2,4 cm.
CODE 01006#001
PCS 12 | BOX 01



COPPETTA 13 cm.
FRUIT BOWL 13 cm.
H 3,9 cm.
CODE 01130#001
PCS 24 | BOX 01



CALOTTA 16 cm.
OATMEAL BOWL 16 cm.
H 4,2 cm.
CODE 01131#001
PCS 24 | BOX 01



CALOTTA 18 cm.
OATMEAL BOWL 18 cm.
H 5,5 cm.
CODE 01008#001
PCS 10 | BOX 01



BOLO LISCI 13,5 cm.
SMOOTH BOWL 13,5 cm.
H 7 cm.
CODE 01056#001
PCS 12 | BOX 01



BOLO LISCI 14,5 cm.
SMOOTH BOWL 14,5 cm.
H 8 cm.
CODE 01057#001
PCS 12 | BOX 01



PIATTO GONDOLA 21 cm.
GONDOLA SMALL 21 cm.
21 X 18 X H 4 cm.
CODE 01244#001
PCS 12 | BOX 01



PIATTO GONDOLA 26 cm.
GONDOLA MEDIUM 26 cm.
26 X 23 X H 4,5 cm.
CODE 01245#001
PCS 12 | BOX 01



PIATTO BISTECCA 27,5 cm.
STEAK PLATE 27,5 cm.
27,5 X 24,5 X H 4 cm.
CODE 01064#001
PCS 06 | BOX 01



PIATTO BISTECCA 30,5 cm.
STEAK PLATE 30,5 cm.
30,5 X 28 X H 4 cm.
CODE 01062#001
PCS 06 | BOX 01



PIATTO OVALE 23 cm.
OVAL PLATE 23 cm.
23 X 15 X H 3 cm.
CODE 01026#001
PCS 15 | BOX 01



PIATTO OVALE 25 cm.
OVAL PLATE 25 cm.
25 X 17 X H 3,2 cm.
CODE 01027#001
PCS 15 | BOX 01



PIATTO OVALE 28 cm.
OVAL PLATE 28 cm.
28 X 18,8 X H 4 cm.
CODE 01028#Z001
PCS 15 | BOX 01



PIATTO OVALE 31 cm.
OVAL PLATE 31 cm.
31 X 20,6 X H 4,5 cm.
CODE 01029#Z001
PCS 10 | BOX 01



PIATTO OVALE 35 cm.
OVAL PLATE 35 cm.
35 X 23,4 X H 4,5 cm.
CODE 01030#001
PCS 10 | BOX 01



PIATTO OVALE 38 cm.
OVAL PLATE 38 cm.
38 X 25,8 X H 5 cm.
CODE 01031#001
PCS 06 | BOX 01



PIATTO PIANO 27 cm.
DINNER PLATE 27 cm.
H 2,8 cm.
CODE 03000#001
PCS 06 | BOX 01



PIATTO PIANO 23,5 cm.
DINNER PLATE 23,5 cm.
H 3 cm.
CODE 03002#001
PCS 12 | BOX 01



PIATTO FONDO 20,5 cm.
SOUP PLATE 20,5 cm.
H 4 cm.
CODE 03003#001
PCS 12 | BOX 01



PIATTO FRUTTA 20 cm.
DESSERT PLATE 20 cm.
H 2,6 cm.
CODE 03004#001
PCS 12 | BOX 01



PIATTO FRUTTA 19 cm.
DESSERT PLATE 19 cm.
H 2,6 cm.
CODE 03005#001
PCS 12 | BOX 01



PIATTO PANE 17 cm.
BREAD PLATE 17 cm.
H 2,5 cm.
CODE 03006#001
PCS 12 | BOX 01



PIATTO OVALE 24 cm.
OVAL PLATE 24 cm.
24 X 15,5 X H 3 cm.
CODE 03034#001
PCS 15 | BOX 01



PIATTO OVALE 27 cm.
OVAL PLATE 27 cm.
27 X 16,7 X H 3,1 cm.
CODE 03035#001
PCS 15 | BOX 01



PIATTO OVALE 32 cm.
OVAL PLATE 32 cm.
32 X 20 X H 3,2 cm.
CODE 03036#001
PCS 10 | BOX 01



PIATTO OVALE 36 cm.
OVAL PLATE 36 cm.
36 X 22,7 X H 3,2 cm.
CODE 03037#001
PCS 06 | BOX 01



PIATTO OVALE CHICAGO 25 cm.
CHICAGO OVAL PLATE 25 cm.
25 X 16,5 X H 2,3 cm.
CODE 03496#001
PCS 10 | BOX 01



PIATTO OVALE CHICAGO 28 cm.
CHICAGO OVAL PLATE 28 cm.
28 X 19,5 X H 2,4 cm.
CODE 03497#001
PCS 10 | BOX 01



PIATTO OVALE CHICAGO 37 cm.
CHICAGO OVAL PLATE 37 cm.
37 X 25 X H 3 cm.
CODE 03499#001
PCS 06 | BOX 01



COPPETTA IMPILABILE 12 cm.
STACKING FRUIT BOWL 12 cm.
H 5 cm.
CODE 03167#001
PCS 24 | BOX 01



INSALATIERA IMPILABILE 15 cm.
STACKING SALAD BOWL 15 cm.
H 6 cm.
CODE 03264#001
PCS 10 | BOX 01



INSALATIERA IMPILABILE 18 cm.
STACKING SALAD BOWL 18 cm.
H 7 cm.
CODE 03258#001
PCS 10 | BOX 01



INSALATIERA IMPILABILE 21 cm.
STACKING SALAD BOWL 21 cm.
H 8 cm.
CODE 03259#001
PCS 06 | BOX 01



INSALATIERA IMPILABILE 24 cm.
STACKING SALAD BOWL 24 cm.
H 9 cm.
CODE 03260#001
PCS 06 | BOX 01



TAZZA CAFFÈ IMPILABILE 8 cl.
STACKING ESPRESSO CUP 8 cl.
CODE 03073#001
PCS 12 | BOX 01



TAZZA THÈ/CAPPUCCINO IMPILABILE 17 cl.
STACKING TEA/CAPPUCCINO CUP 17 cl.
CODE 03077#001
PCS 12 | BOX 01



TAZZA LATTE IMPILABILE 25 cl.
STACKING MILK CUP 25 cl.
CODE 03079#001
PCS 12 | BOX 01



TEIERA 30 cl.
TEAPOT 30 cl.
CODE 03132#001
PCS 06 | BOX 01



TEIERA 50 cl.
TEAPOT 50 cl.
CODE 03133#001
PCS 06 | BOX 01

P. CAFFÈ 12 cm.
ESPRESSO SAUCER 12 cm.
CODE 03074#001
PCS 24 | BOX 01

P. THÈ/CAPPUCCINO 14 cm.
TEA/CAPPUCCINO SAUCER 14 cm.
CODE 03078#001
PCS 24 | BOX 01

P. LATTE 15 cm.
MILK SAUCER 15 cm.
CODE 03080#001
PCS 24 | BOX 01



LATTIERA 6 cl.
JUG/CREAMER 6 cl.
CODE 03250#001
PCS 06 | BOX 01



LATTIERA 13 cl.
JUG/CREAMER 13 cl.
CODE 03251#001
PCS 06 | BOX 01



LATTIERA 17 cl.
JUG/CREAMER 17 cl.
CODE 03252#001
PCS 06 | BOX 01



LATTIERA 21 cl.
JUG/CREAMER 21 cl.
CODE 03253#001
PCS 06 | BOX 01



LATTIERA 46 cl.
JUG/CREAMER 46 cl.
CODE 03254#001
PCS 06 | BOX 01



LATTIERA 61 cl.
JUG/CREAMER 61 cl.
CODE 03255#001
PCS 06 | BOX 01



TAZZA CLARA CAFFÈ 9 cl.
ESPRESSO CUP CLARA 9 cl.
CODE 13270#001
PCS 12 | BOX 01

P. CLARA CAFFÈ 12 cm.
ESPRESSO SAUCER 12 cm.
CODE 03074#001
PCS 24 | BOX 01



TAZZA CLARA CAPPUCCINO/THÈ 16,5 cl.
CAPPUCCINO/TEA CUP CLARA 16,5 cl.
CODE 13272#001
PCS 12 | BOX 01

P. CLARA CAPPUCCINO/THÈ 14 cm.
CAPPUCCINO/TEA SAUCER 14 cm.
CODE 03078#001
PCS 24 | BOX 01



TAZZA AROMA CAFFÈ 9 cl.
ESPRESSO CUP AROMA 9 cl.
CODE 13282#001
PCS 12 | BOX 01

P. AROMA CAFFÈ 12 cm.
ESPRESSO SAUCER 12 cm.
CODE 03074#001
PCS 24 | BOX 01



TAZZA AROMA CAPPUCCINO/THÈ 16,5 cl.
CAPPUCCINO/TEA CUP AROMA 16,5 cl.
CODE 13284#001
PCS 12 | BOX 01

P. AROMA CAPPUCCINO/THÈ 14 cm.
CAPPUCCINO/TEA SAUCER 14 cm.
CODE 03078#001
PCS 24 | BOX 01



PIATTO PIANO 28 cm.
DINNER PLATE 28 cm.
H 2 cm.
CODE 14466#001
PCS 06 | BOX 01



PIATTO PIANO 26 cm.
DINNER PLATE 26 cm.
H 2 cm.
CODE 14001#001
PCS 12 | BOX 01



PIATTO FONDO 23 cm.
SOUP PLATE 23 cm.
H 3,5 cm.
CODE 14003#001
PCS 12 | BOX 01



PIATTO FRUTTA 21 cm.
DESSERT PLATE 21 cm.
H 2 cm.
CODE 14004#001
PCS 12 | BOX 01



P. PORTATA 31 cm.
ROUND DISH 31 cm.
H 2 cm.
CODE 14017#001
PCS 04 | BOX 01



P. PORTATA 32,5 cm.
ROUND DISH 32,5 cm.
H 2 cm.
CODE 14390#001
PCS 04 | BOX 01



INSALATIERA COUP 17 cm.
SALAD BOWL 17 cm.
H 7,7 cm.
CODE 14362#001
PCS 06 | BOX 01



INSALATIERA COUP 21 cm.
SALAD BOWL 21 cm.
H 9 cm.
CODE 14363#001
PCS 06 | BOX 01



INSALATIERA COUP 25 cm.
SALAD BOWL 25 cm.
H 10,3 cm.
CODE 14319#001
PCS 04 | BOX 01



COPPETTA 15 cm.
FRUIT BOWL 15 cm.
H 4 cm.
CODE 14020#001
PCS 12 | BOX 01



INSALATIERA C/FALDA 25 cm.
RIMMED SALAD BOWL 25 cm.
H 6 cm.
CODE 014011#001
PCS 04 | BOX 01



TAZZA CAFFÈ 9 cl.
ESPRESSO CUP 9 cl.
H 5 cm.
CODE 14421#001
PCS 06 | BOX 01

P. CAFFÈ 12 cm.
ESPRESSO SAUCER 12 cm.
CODE 14096#001
PCS 24 | BOX 01



TAZZA JUMBO 50 cl.
JUMBO CUP 50 cl.
H 8,4 cm.
CODE 14411#001
PCS 06 | BOX 01



TAZZA MUG 34 cl.
MUG 34 cl.
H 9,5 cm.
CODE 14401#001
PCS 06 | BOX 01



PIATTO PIANO 28 cm.
DINNER PLATE 28 cm.
H 2,5 cm.
CODE 22466#001
PCS 06 | BOX 01



PIATTO PIANO 26 cm.
DINNER PLATE 26 cm.
H 2,5 cm.
CODE 22001#001
PCS 12 | BOX 01



PIATTO FONDO 22 cm.
SOUP PLATE 22 cm.
H 4,2 cm.
CODE 22003#001
PCS 12 | BOX 01



PIATTO FRUTTA 21 cm.
DESSERT PLATE 21 cm.
H 2,2 cm.
CODE 22004#001
PCS 12 | BOX 01



PIATTO PANE 17 cm.
BREAD PLATE 17 cm.
H 2,2 cm.
CODE 22006#001
PCS 12 | BOX 01



P. PORTATA 31 cm.
ROUND PLATE 31 cm.
H 2,5 cm.
CODE 22017#001
PCS 04 | BOX 01



PIATTO OVALE 28 cm.
OVAL PLATE 28 cm.
28 X 24 X H 2,5 cm.
CODE 22028#001
PCS 10 | BOX 01



PIATTO OVALE 34 cm.
OVAL PLATE 34 cm.
34 X 29,5 X H 2,7 cm.
CODE 22038#001
PCS 06 | BOX 01



COPPETTA 14,5 cm.
BOWL 14,5 cm.
H 4 cm.
CODE 22057#001
PCS 12 | BOX 01



INSALATIERA COUP 20 cm.
COUP SALAD BOWL 20 cm.
H 7,5 cm.
CODE 22547#001
PCS 06 | BOX 01



INSALATIERA COUP 23 cm.
COUP SALAD BOWL 23 cm.
H 7,5 cm.
CODE 22260#001
PCS 06 | BOX 01



PIATTO PIZZA 28 cm.
PIZZA PLATE 28 cm.
H 1,7 cm.
CODE 04016#001
PCS 06 | BOX 01



PIATTO PIZZA 31 cm.
PIZZA PLATE 31 cm.
H 1,7 cm.
CODE 04019#001
PCS 06 | BOX 01



PIATTO PIZZA 33 cm.
PIZZA PLATE 33 cm.
H 1,8 cm.
CODE 04018#001
PCS 06 | BOX 01



PIATTO PIZZA 35 cm.
PIZZA PLATE 35 cm.
H 1,8 cm.
CODE 04013#001
PCS 06 | BOX 01



K-BOWL 15 cm.
K-BOWL 15 cm.
Ø INT. 7 X H 3,6 cm.
CODE 04485#001
PCS 12 | BOX 01



K-BOWL 20 cm.
K-BOWL 20 cm.
Ø INT. 9,7 X H 4,6 cm.
CODE 04486#001
PCS 12 | BOX 01



K-BOWL 24 cm.
K-BOWL 24 cm.
Ø INT. 12,5 X H 5,2 cm.
CODE 04487#001
PCS 06 | BOX 01



K-BOWL 27,5 cm.
K-BOWL 27,5 cm.
Ø INT. 14,5 X H 6 cm.
CODE 04488#001
PCS 06 | BOX 01



B-BOWL TOP 26 cm.
B-BOWL TOP 26 cm.
H 5 cm.
CODE 04515#001
PCS 06 | BOX 01



B-BOWL TOP 30 cm.
B-BOWL TOP 30 cm.
H 5,2 cm.
CODE 04516#001
PCS 06 | BOX 01



PASTA BOWL LISCIO 23 cm.
PASTA BOWL 23 cm.
H 5 cm.
CODE 04238#001
PCS 10 | BOX 01



PASTA BOWL LISCIO 26,5 cm.
PASTA BOWL 26,5 cm.
H 5 cm.
CODE 04248#001
PCS 06 | BOX 01



PASTA BOWL LISCIO 30 cm.
PASTA BOWL 30 cm.
H 6 cm.
CODE 04249#001
PCS 06 | BOX 01



PIATTO P. KONOS 28 cm.
KONOS ROUND DISH 28 cm.
H 3,8 cm.
CODE 04551#001
PCS 06 | BOX 01



PIATTO P. KONOS 32 cm.
KONOS ROUND DISH 32 cm.
H 4,7 cm.
CODE 04552#001
PCS 04 | BOX 01



**PIATTO GRAN FONDO
COUSCOUS 26 cm.**
LARGE DEEP PLATE 26 cm.
(COUSCOUS)
H 4,7 cm.
CODE 04025#001
PCS 06 | BOX 01



PIATTO PIANO GOURMET 31 cm.
DINNER PLATE GOURMET 31 cm.
H 3,3 cm.
CODE 04517#001
PCS 04 | BOX 01



COPPETTA CONICA 9 cm.
CONIC BOWL 9 cm.
H 4,6 cm.
CODE 04436#001
PCS 24 | BOX 01



COPPETTA CONICA 13 cm.
CONIC BOWL 13 cm.
H 5,6 cm.
CODE 04491#001
PCS 12 | BOX 01



INSALATIERA CONICA 16 cm.
CONIC SALAD BOWL 16 cm.
H 6,5 cm.
CODE 04492#001
PCS 12 | BOX 01



INSALATIERA CONICA 18 cm.
CONIC SALAD BOWL 18 cm.
H 8 cm.
CODE 04493#001
PCS 10 | BOX 01



INSALATIERA CONICA 20 cm.
CONIC SALAD BOWL 20 cm.
H 8,9 cm.
CODE 04494#001
PCS 10 | BOX 01



INSALATIERA CONICA 24 cm.
CONIC SALAD BOWL 24 cm.
H 10,4 cm.
CODE 04495#001
PCS 06 | BOX 01



PIATTO TRIS 26,5 cm.
THREE-SECTIONS BUFFET DISH
26,5 cm.
H 2,6 cm.
CODE 04046#001
PCS 06 | BOX 01



PIATTO TRIS 30 cm.
THREE-SECTIONS BUFFET DISH
30 cm.
H 3 cm.
CODE 04389#001
PCS 06 | BOX 01



PIATTO BIS 26,5 cm.
TWO-SECTIONS BUFFET DISH
26,5 cm.
H 2,7 cm.
CODE 04197#001
PCS 06 | BOX 01



PIATTO BIS 30 cm.
TWO-SECTIONS BUFFET DISH
30 cm.
H 3 cm.
CODE 04388#001
PCS 06 | BOX 01



CARAVELLA 27X19 cm.
CARAVEL 27X19 cm.
H 4,3 cm.
CODE 04519#001
PCS 06 | BOX 01



CARAVELLA 30X21 cm.
CARAVEL 30X21 cm.
H 4,6 cm.
CODE 04520#001
PCS 06 | BOX 01



CARAVELLA 35X24,5 cm.
CARAVEL 35X24,5 cm.
H 5,2 cm.
CODE 04521#001
PCS 04 | BOX 01



INSALATIERA COSTOLATA 17 cm.
EMBOSSED SALAD BOWL 17 cm.
H 6 cm.
CODE 04304#001
PCS 10 | BOX 01



INSALATIERA COSTOLATA 20 cm.
EMBOSSED SALAD BOWL 20 cm.
H 7,5 cm.
CODE 04305#001
PCS 06 | BOX 01



INSALATIERA COSTOLATA 23 cm.
EMBOSSED SALAD BOWL 23 cm.
H 8,7 cm.
CODE 04306#001
PCS 06 | BOX 01



INSALATIERA COSTOLATA 26 cm.
EMBOSSED SALAD BOWL 26 cm.
H 9 cm.
CODE 04307#001
PCS 06 | BOX 01



BOLO IMPILABILE 8,5 cm.
STACKING BOWL 8,5 cm.
H 4,7 cm.
CODE 04168#001
PCS 24 | BOX 01



BOLO COSTOLATO 14 cm.
EMBOSSED BOWL 14 cm.
H 7,5 cm.
CODE 04162#001
PCS 12 | BOX 01



**PIROFILA OVALE
LISCIA** 19 cm.
OVAL BAKING DISH 19 cm.
19 X 12 X H 4 cm.
CODE 07105#001
PCS 06 | BOX 01



**PIROFILA OVALE
LISCIA** 22 cm.
OVAL BAKING DISH 22 cm.
22 X 14 X H 4,5 cm.
CODE 07100#001
PCS 06 | BOX 01



**PIROFILA OVALE
LISCIA** 28 cm.
OVAL BAKING DISH 28 cm.
28 X 17 X H 4,8 cm.
CODE 07101#001
PCS 04 | BOX 01



**PIROFILA OVALE
LISCIA** 32 cm.
OVAL BAKING DISH 32 cm.
32 X 20 X H 5 cm.
CODE 07102#001
PCS 01 | BOX 01



**PIROFILA OVALE
LISCIA** 36 cm.
OVAL BAKING DISH 36 cm.
36 X 23,8 X H 5,3 cm.
CODE 07103#001
PCS 01 | BOX 01



**PIROFILA OVALE
LISCIA** 42 cm.
OVAL BAKING DISH 42 cm.
42 X 26 X H 5,5 cm.
CODE 07135#001
PCS 01 | BOX 01



**PIROFILA OVALE
LISCIA** 46 cm.
OVAL BAKING DISH 46 cm.
46 X 27,4 X H 5,6 cm.
CODE 07104#001
PCS 01 | BOX 01



**PIROFILA OVALE
CARATTERIZZATA** 19 cm.
OVAL EMBOSSED
BAKING DISH 19 cm.
19 X 12 X H 4,2 cm.
CODE 07111#001
PCS 06 | BOX 01



**PIROFILA OVALE
CARATTERIZZATA** 22 cm.
OVAL EMBOSSED
BAKING DISH 22 cm.
22 X 13,5 X H 4,5 cm.
CODE 07230#001
PCS 06 | BOX 01



**PIROFILA OVALE
CARATTERIZZATA** 28 cm.
OVAL EMBOSSED
BAKING DISH 28 cm.
28 X 16,6 X H 4,8 cm.
CODE 07231#001
PCS 04 | BOX 01



**PIROFILA OVALE
CARATTERIZZATA** 32 cm.
OVAL EMBOSSED
BAKING DISH 32 cm.
32 X 19,6 X H 5 cm.
CODE 07232#001
PCS 01 | BOX 01



**PIROFILA OVALE
CARATTERIZZATA** 36 cm.
OVAL EMBOSSED
BAKING DISH 36 cm.
36 X 23 X H 5,3 cm.
CODE 07233#001
PCS 01 | BOX 01



**PIROFILA OVALE
CARATTERIZZATA** 42 cm.
OVAL EMBOSSED
BAKING DISH 42 cm.
42 X 25,4 X H 5,5 cm.
CODE 07235#001
PCS 01 | BOX 01



**PIROFILA OVALE
CARATTERIZZATA** 46 cm.
OVAL EMBOSSED
BAKING DISH 46 cm.
46 X 27,4 X H 5,6 cm.
CODE 07234#001
PCS 01 | BOX 01



PIROFILA RETT.RE LISCIA 19 cm.
RECTANGULAR BAKING DISH
19 cm.
19 X 12 X H 4 cm.
CODE 07106#001
PCS 06 | BOX 01



PIROFILA RETT.RE LISCIA 22 cm.
RECTANGULAR BAKING DISH
22 cm.
22 X 14 X H 4,5 cm.
CODE 07148#001
PCS 06 | BOX 01



PIROFILA RETT.RE LISCIA 28 cm.
RECTANGULAR BAKING DISH
28 cm.
28 X 19,5 X H 5 cm.
CODE 07149#001
PCS 04 | BOX 01



PIROFILA RETT.RE LISCIA 32 cm.
RECTANGULAR BAKING DISH
32 cm.
32 X 22 X H 5,5 cm.
CODE 07163#001
PCS 01 | BOX 01



PIROFILA RETT.RE LISCIA 36 cm.
RECTANGULAR BAKING DISH
36 cm.
36 X 26 X H 6 cm.
CODE 07150#001
PCS 01 | BOX 01



PIROFILA RETT.RE LISCIA 40 cm.
RECTANGULAR BAKING DISH
40 cm.
40 X 27,5 X H 6,5 cm.
CODE 07545#001
PCS 01 | BOX 01



PIROFILA QUADRA LISCIA 16 cm.
SQUARE BAKING DISH 16 cm.
16 X 16 X H 3,6 cm.
CODE 07527#001
PCS 02 | BOX 01



PIROFILA QUADRA LISCIA 20 cm.
SQUARE BAKING DISH 20 cm.
20 X 20 X H 3,8 cm.
CODE 07528#001
PCS 02 | BOX 01



PIROFILA QUADRA LISCIA 23 cm.
SQUARE BAKING DISH 23 cm.
23 X 23 X H 4,4 cm.
CODE 07529#001
PCS 02 | BOX 01



PIROFILA QUADRA LISCIA 26 cm.
SQUARE BAKING DISH 26 cm.
26 X 26 X H 5,3 cm.
CODE 07530#001
PCS 02 | BOX 01



PIROFILA QUADRA LISCIA 29 cm.
SQUARE BAKING DISH 29 cm.
29 X 29 X H 5,6 cm.
CODE 07531#001
PCS 02 | BOX 01



PIATTO PIANO 26 cm.
DINNER PLATE 26 cm.
H 2,2 cm.
CODE 19001#001
PCS 12 | BOX 01



PIATTO FONDO 23 cm.
SOUP PLATE 23 cm.
H 3,5 cm.
CODE 19003#001
PCS 12 | BOX 01



PIATTO FRUTTA 21 cm.
DESSERT PLATE 21 cm.
H 2 cm.
CODE 19004#001
PCS 12 | BOX 01



PIATTO PANE 17 cm.
BREAD PLATE 17 cm.
H 2 cm.
CODE 19006#001
PCS 12 | BOX 01



P. PORTATA 31 cm.
ROUND PLATE 31 cm.
H 2 cm.
CODE 19017#001
PCS 04 | BOX 01



PIATTO PIANO 28 cm.
DINNER PLATE 28 cm.
H 2,2 cm.
CODE 17466#001
PCS 06 | BOX 01



PIATTO PIANO 26 cm.
DINNER PLATE 26 cm.
H 2,2 cm.
CODE 17001#001
PCS 12 | BOX 01



PIATTO FONDO 23 cm.
SOUP PLATE 23 cm.
H 3,9 cm.
CODE 17003#001
PCS 12 | BOX 01



PIATTO FRUTTA 21 cm.
DESSERT PLATE 21 cm.
H 2 cm.
CODE 17004#001
PCS 12 | BOX 01



PIATTO PANE 17 cm.
BREAD PLATE 17 cm.
H 2 cm.
CODE 17006#001
PCS 12 | BOX 01



P. PORTATA 31 cm.
ROUND PLATE 31 cm.
H 2,4 cm.
CODE 17017#001
PCS 04 | BOX 01



COPPETTA 13 cm.
BOWL 13 cm.
H 3,3 cm.
CODE 17464#001
PCS 24 | BOX 01



INSALATIERA 19 cm.
SALAD BOWL 19 cm.
H 5 cm.
CODE 17007#001
PCS 10 | BOX 01



INSALATIERA 26 cm.
SALAD BOWL 26 cm.
H 6,3 cm.
CODE 17011#001
PCS 04 | BOX 01



PIATTO PIANO 26 cm.
DINNER PLATE 26 cm.
H 2,5 cm.
CODE 18001#001
PCS 12 | BOX 01



PIATTO FONDO 23 cm.
SOUP PLATE 23 cm.
H 3,8 cm.
CODE 18003#001
PCS 12 | BOX 01



PIATTO FRUTTA 21 cm.
DESSERT PLATE 21 cm.
H 2,2 cm.
CODE 18004#001
PCS 12 | BOX 01



PIATTO PANE 17 cm.
BREAD PLATE 17 cm.
H 2,5 cm.
CODE 18006#001
PCS 12 | BOX 01



P. PORTATA 31 cm.
ROUND PLATE 31 cm.
H 2,3 cm.
CODE 18017#001
PCS 04 | BOX 01



INSALATIERA 26 cm.
SALAD BOWL 26 cm.
H 7,5 cm.
CODE 18011#001
PCS 04 | BOX 01



PIATTO PIANO 26 cm.
DINNER PLATE 26 cm.
H 2 cm.
CODE 12001#001
PCS 12 | BOX 01



PIATTO FONDO 23 cm.
SOUP PLATE 23 cm.
H 3,5 cm.
CODE 12003#001
PCS 12 | BOX 01



PIATTO FRUTTA 21 cm.
DESSERT PLATE 21 cm.
H 1,9 cm.
CODE 12004#001
PCS 12 | BOX 01



PIATTO PANE 17 cm.
BREAD PLATE 17 cm.
H 2 cm.
CODE 12006#001
PCS 12 | BOX 01



P. PORTATA 31 cm.
ROUND PLATE 31 cm.
H 2,2 cm.
CODE 12017#001
PCS 04 | BOX 01



PIATTO PIANO 26 cm.
DINNER PLATE 26 cm.
H 2,5 cm.
CODE 11001#001
PCS 12 | BOX 01



PIATTO FONDO 22,5 cm.
SOUP PLATE 22,5 cm.
H 3,8 cm.
CODE 11003#001
PCS 12 | BOX 01



PIATTO FRUTTA 21 cm.
DESSERT PLATE 21 cm.
H 2,1 cm.
CODE 11004#001
PCS 12 | BOX 01



PIATTO PANE 17 cm.
BREAD PLATE 17 cm.
H 2 cm.
CODE 11006#001
PCS 12 | BOX 01



P. PORTATA 31 cm.
ROUND PLATE 31 cm.
H 2,1 cm.
CODE 11017#001
PCS 04 | BOX 01



PIATTO PIANO 28 cm.
FLAT PLATE 28 cm.
DIAG. 31,8 cm. - H 2,7 cm.
CODE 23466#001
PCS 06 | BOX 01



PIATTO PIANO 26 cm.
FLAT PLATE 26 cm.
DIAG. 29,8 cm. - H 2,4 cm.
CODE 23001#001
PCS 06 | BOX 01



PIATTO PIANO 23 cm.
FLAT PLATE 23 cm.
DIAG. 26,1 cm. - H 2 cm.
CODE 23002#001
PCS 12 | BOX 01



PIATTO FONDO 21 cm.
DEEP PLATE 21 cm.
DIAG. 23,3 cm. - H 4,3 cm.
CODE 23003#001
PCS 06 | BOX 01



PIATTO FONDO 18 cm.
DEEP PLATE 18 cm.
DIAG. 20,5 cm. - H 4,1 cm.
CODE 23452#001
PCS 15 | BOX 01



PIATTO FRUTTA 21 cm.
DESSERT PLATE 21 cm.
DIAG. 23,7 cm. - H 2,5 cm.
CODE 23004#001
PCS 06 | BOX 01



PIATTO PANE 17 cm.
BREAD PLATE 17 cm.
DIAG. 18,6 cm. - H 1,9 cm.
CODE 23006#001
PCS 10 | BOX 01



P. PORTATA 31 cm.
FLAT PLATE 31 cm.
DIAG. 35 cm. - H 2,9 cm.
CODE 23017#001
PCS 04 | BOX 01



PIATTO PIANO QUADRO 26 cm.
FLAT SQUARE PLATE 26 cm.
DIAG. 31,5 cm. - H 3 cm.
CODE 20001#001
PCS 06 | BOX 01



PIATTO PIANO QUADRO 24 cm.
FLAT SQUARE PLATE 24 cm.
DIAG. 28 cm. - H 2,5 cm.
CODE 20002#001
PCS 06 | BOX 01



PIATTO FONDO QUADRO 21 cm.
DEEP SQUARE PLATE 21 cm.
DIAG. 24,5 cm. - H 4,5 cm.
CODE 20003#001
PCS 06 | BOX 01



PIATTO FRUTTA QUADRO 21 cm.
DESSERT SQUARE PLATE 21 cm.
DIAG. 24,5 cm. - H 2,8 cm.
CODE 20004#001
PCS 06 | BOX 01



PIATTO PANE QUADRO 17 cm.
BREAD SQUARE PLATE 17 cm.
DIAG. 20 cm. - H 2,2 cm.
CODE 20006#001
PCS 10 | BOX 01



INSALATIERA QUADRA 17,5 cm.
SQUARE SALAD BOWL 17,5 cm.
DIAG. 20,5 cm. - H 6 cm.
CODE 20481#001
PCS 10 | BOX 01



P. PORTATA QUADRO 31 cm.
FLAT SQUARE PLATE 31 cm.
DIAG. 37 cm. - H 3,5 cm.
CODE 20017#001
PCS 04 | BOX 01



RETTANGOLO 25X14 cm.
FLAT RECTANGULAR PLATE
25X14 cm.
DIAG. 26 cm. - H 2,5 cm.
CODE 20483#001
PCS 10 | BOX 01



RETTANGOLO 30X18 cm.
FLAT RECTANGULAR PLATE
30X18 cm.
DIAG. 31 cm. - H 3 cm.
CODE 20482#001
PCS 06 | BOX 01



RETTANGOLO 36X21 cm.
FLAT RECTANGULAR PLATE
36X21 cm.
DIAG. 38 cm. - H 3,5 cm.
CODE 20484#001
PCS 06 | BOX 01



RETTANGOLO SAGOMATO 31X25 cm.
RECTANGULAR SHAPED DISH
31X25 cm.
DIAG. 36 cm. - H 3 cm.
CODE 20490#001
PCS 04 | BOX 01



RETTANGOLO FONDO 34X24,5 cm.
DEEP RECTANGULAR
34X24,5 cm.
DIAG. 37 cm. - H 3,5 cm.
CODE 20522#001
PCS 04 | BOX 01



COPPETTA QUADRA 8 cm.
SQUARE SALAD BOWL 8 cm.
H 3,5 cm.
CODE 20479#001
PCS 12 | BOX 01



COPPETTA QUADRA 12 cm.
SQUARE SALAD BOWL 12 cm.
H 4 cm.
CODE 20480#001
PCS 12 | BOX 01



COPPETTA QUADRA 14 cm.
SQUARE SALAD BOWL 14 cm.
H 4,2 cm.
CODE 20469#001
PCS 12 | BOX 01



SET 6 CAFFÈ C/P 7,5 cl.
ESPRESSO CUP 7,5 cl.
ESPRESSO SAUCER 10,5 cm.
CODE 20082#001
PCS 01 | BOX 01



SET 4 THÉ/CAPPUCCINO C/P 17,5 cl.
TEA/CAPPUCCINO CUP 7,5 cl.
TEA/CAPPUCCINO SAUCER 13 cm.
CODE 20084#001
PCS 01 | BOX 01



SET 4 LATTE C/P 27,5 cl.
MILK CUP 27,5 cl.
MILK SAUCER 14 cm.
CODE 20085#001
PCS 01 | BOX 01



PIATTO PIANO 27 cm.
FLAT SQUARE PLATE 27 cm.
DIAG.INT. 26,5 cm. - H 2,8 cm.
CODE 24000#001
PCS 06 | BOX 01



PIATTO PIANO 24 cm.
FLAT SQUARE PLATE 24 cm.
DIAG.INT. 24 cm. - H 2,7 cm.
CODE 24002#001
PCS 06 | BOX 01



PIATTO FONDO 20 cm.
DEEP SQUARE PLATE 20 cm.
DIAG.INT. 17 cm. - H 4,8 cm.
CODE 24003#001
PCS 06 | BOX 01



PIATTO FRUTTA 21 cm.
DESSERT SQUARE PLATE 21 cm.
DIAG.INT. 20,5 cm. - H 2,5 cm.
CODE 24004#001
PCS 06 | BOX 01



PIATTO PIANO
PETIT MULTIUSO 14 cm.
FLAT PLATE MULTIPURPOSE
PETIT 14 cm.
DIAG.INT. 14 cm. - H 1,8 cm.
CODE 24511#001
PCS 24 | BOX 01



P. PORTATA 31 cm.
FLAT SQUARE PLATE 31 cm.
DIAG.INT. 29,5 cm. - H 3 cm.
CODE 24017#001
PCS 04 | BOX 01




RETTANGOLO 26X15 cm.
FLAT RECTANGULAR PLATE
26X15 cm.
DIAG.INT. 28,5 cm. - H 2,3 cm.
CODE 24523#001
PCS 10 | BOX 01



RETTANGOLO 29X17,5 cm.
FLAT RECTANGULAR PLATE
29X17,5 cm.
DIAG.INT. 33,4 cm. - H 2,4 cm.
CODE 24524#001
PCS 06 | BOX 01



RETTANGOLO 34X14 cm.
FLAT RECTANGULAR PLATE
34X14 cm.
DIAG.INT. 27,5 cm. - H 3 cm.
CODE 24509#001
PCS 04 | BOX 01



RETTANGOLO 34X18 cm.
FLAT RECTANGULAR PLATE
34X18 cm.
DIAG.INT. 28,5 cm. - H 3 cm.
CODE 24510#001
PCS 04 | BOX 01